

TOTARA MODEL

FLUE SYSTEM INSTALLATION INSTRUCTIONS

- This flue system is the genuine factory flue for the Woodsman Totara, and is complete with Woodsman Crusader bird resistant Cowl.
- It is recommended that the Installation of any solid fuel appliance should be carried out by suitably trained and qualified personnel.
- Inspect the chimney for any cracks, flaws or missing mortar, and repair to a suitable standard if required.
- Positioning and clearance instructions for your Totara are given on the instruction sheet supplied inside each firebox.
- Each flue length should be joined with the male section on top and flue cement should be applied to all 150mm flue joins as well as the spigot. The flue lengths must be fixed together using three stainless steel rivets or self tapping screws.
- Trim the top length of flue pipe allowing for heat expansion and fit the Crusader cowl.



